

Home Page

Settings

System Administration

Administrator Password (User Accounts off only)

On/Off

Privileges (User Accounts off only)

Allow Saving of Presets

On/Off

Allow Folder Selection

On/Off

Allow Network Folder Selection

On/Off

Allow Change Filename

On/Off

Auto detection of USB drive

On/Off

Allow Scan to Email

On/Off

Allow Scan to Cloud

On/Off

Allow Print from Cloud

On/Off

User Accounts

User Account

On/Off

User Account

Local/Active Directory

Logon Details -> Use Name (Local User Accounts only)

On/Off

Logon Details -> Use Password (Local User Accounts only)

On/Off

Edit User

Select User

User

Password (Local User Accounts only)

User / Power User (Not Administrator)

Set User's Scan Folder (Not Administrator)

On/Off

Folder path

Local

On/Off

Network

On/Off

Type

Server / FTP / FTP (SSL)

Server

Subfolder
User
Password
Domain
Test Network Connection

Add User (Local User Accounts only)

User
Password
User / Power User
Set User's Scan Folder
 On/Off
 Local
 On/Off
 Folder path
 Network
 On/Off
 Type
 Server / FTP / FTP (SSL)
 Server
 Subfolder
 User
 Password
 Domain
 Test Network Connection

Delete User

Privileges

User Privileges
 Allow Saving of Preset
 On/Off
 Allow Folder Selection
 On/Off
 Allow Change Filename
 On/Off
 Auto detection of USB drive
 On/Off
 Allow Scan to Email
 On/Off
 Allow DropBox cloud access
 On/Off
 Allow Box cloud access
 On/Off
 Allow Scan to Cloud
 On/Off
 Allow Print from Cloud
 On/Off
Power User Privileges
 Allow Saving of Preset
 On/Off

Allow Folder Selection
On/Off

Allow Change Filename
On/Off

Auto detection of USB drive
On/Off

Allow Scan to Email
On/Off

Allow DropBox cloud access
On/Off

Allow Box cloud access
On/Off

Allow Scan to Cloud
On/Off

Allow Print from Cloud
On/Off

Allow Access to Program Preferences
On/Off

Allow Access to Printer Settings
On/Off

Allow Access to Scanner Settings
On/Off

Allow Access to File Settings
On/Off

Allow Access to Preset Settings
On/Off

Export Users (Local User Accounts only)

Import Users (Local User Accounts only)

Usage Log

User

Time span

Today

This Week

This Month

This Year

Custom

Start Date

End Date

Export

Email

Email Settings

SMTP Server

Use SSL

On/Off

Port Number

Domain

Email Address

Password

Automatically Send Emails

On/Off

Frequency

Daily/Weekly/Monthly

File Management

Save files to USB drive

Delete

Email Settings

Scan to Email Default Settings

Simple Mail Transfer Protocol (SMTP)

SMTP Server

Port Number

Domain

Use SSL

On/Off

Message Settings

Subject

Message Body

Max Attachment Size

Auto Reduce Attachment size

On/Off

SMTP Default Login Information

Use Single Email Address for users (User Accounts on only)

On/Off

Email Address

Use for Users (User Accounts on only)

On/Off

User for Power Users (User Accounts on only)

On/Off

Password

Keep Password

On/Off

Administration Email Settings

Simple Mail Transfer Protocol (SMTP)

SMTP Server

Use SSL

On/Off

Port Number

Domain

Email Address

Password

Accounting

Accounting

On/Off

Account ID

On/Off

Department

On/Off
Project Number
On/Off
Order Number
On/Off
Customer ID
On/Off
Job Number
On/Off
Comment
On/Off

Printer Help

On/Off

Scanner Settings

Export

System Settings

System Update and Recovery (System reboots into Update Mode)

Cancel (System reboots into Normal System Mode)

System Recovery

Choose image

Install image

Select Settings to use

User Settings / Factory Settings

System Update

Choose image from USB drive

Install image

Select Settings to use

User Settings / Factory Settings

System Information

Factory Defaults

Reset All

Delete All Users

Delete All User Presets

Delete All Logs

Set Date and Time

Date

Day

Month

Year

Time

Minute

Hour

Time Zone

Network Settings

System IP Address

Obtain IP Address automatically

On/Off

System IP Address

Subnet Mask

Default Gateway

DNS1

DNS2

Computer Name

Computer Name

Join Domain

Domain

Admin Username

Admin Password

Remove from Domain

Domain

Admin Username

Admin Password

System Security Update

Remote Management

Remote Management

On/Off

Port Number

Export System logs