Lm Scanner – Quick Start Guide




Model/Product – UD56T/UC56T, Lm36/Lm24

Manufacturer - Global Scanning Suzhou Co. Ltd #39 Dongjing Industrial Zone #9 Dongfu Road, Suzhou Industrial Park Suzhou, Jiangsu, 215123 CHINA

Contents


1.	Installation to a printer	. 2
2.	Connect Power and Network	.5
3.	ScanAppL Installation	.6
4.	Quick Copy	.7
5.	Quick Scan to USB	.8
6	Quick Scan to DC	0

1. Installation to a printer





Remove panel from the printer as shown.




Fit the left scanner mount using 2 screws supplied, then replace cover with 1 screw.



Right side:


Remove panel from the printer as shown.



Fit the left scanner mount using 2 screws supplied, then replace cover with 1 screw.



Place the scanner's feet in the holes on top of the scanner mounts and pull the scanner to the front.



Secure in place using the 2 thumb screws provided.



Fit Cable Clip.

P/N: 5600T340 _ UG15701-2




Fit Document Return Guides to scanner. (1 for Lm24, 3 for Lm36)



Remove shipping packing from scanner.

2. Connect Power and Network



Connect power and network cables.



Power on.



Download user guides and ScanAppL software from - www.mfpdownload.com




Read Documentation.

3. ScanAppL Installation




Select Language

Accept License Agreement



Configure scanner network address

4. Quick Copy




Insert document into the centre of the scanner, face up.





Select COPY function and press the Green button.




Select target printer.




Collect your copy from the printer.


5. Quick Scan to USB



Insert USB memory stick (FAT32, 128GB max). Do not use a USB extension cable.



Insert document into the centre of the scanner, face up.



Select SCAN to USB function and press the Green button.






Wait before removing USB stick.


6. Quick Scan to PC




Ensure "ScanAppL" is running



Insert document into the centre of the scanner, face up.



Select SCAN to PC function and press the Green button.



Select target PC.





Wait for transfer to PC.